
## ELECTRIC WINDOWS

**Before closing a window care must be taken to ensure that none of the occupants have any part of their body in a position where it could be trapped. Serious injury or death can occur.**


**Ensure that you remove the ignition key when leaving occupants in the vehicle. This will prevent unsupervised operation of the windows, which may result in injury.**




With the ignition on, or engine running,

- Press the lower part of the switch to lower a window.
- Press the upper part of the switch to raise a window.
- Release the switch to stop window movement.

## SLIDING WINDOWS




Squeeze either type of lock and slide the window to the desired position. Release the lock and ensure that the catch is located securely into a locking socket.