4. Select the desired telephone from the list of stored telephones.
5. Select **DISCONNECT**. The audio system will display a confirmation message.
6. Press and hold the back button to close the setup menu.

DELETING A PAIRED PHONE

1. Press and hold **AUDIO/SETUP** to open the setup menu.
2. Select **BLUETOOTH**.
3. Select **PAIRED DEV**.
4. Select the desired telephone from the list of stored telephones.
5. Select **CLEAR**. The audio system will display a confirmation message.
6. Press and hold the back button to close the setup menu.

PHONEBOOK

Up to 1000 names (with 5 telephone numbers per name) can be downloaded from the telephone.

1. Press and hold **AUDIO/SETUP** to open the setup menu.
2. Select **BLUETOOTH**.
3. Select **PHONE BOOK**.
4. Select the desired telephone number and press the menu select control to begin the call.

The downloaded phonebook can be updated automatically.

1. Press and hold **AUDIO/SETUP** to open the setup menu.
2. Select **BLUETOOTH**.
3. Select **PB UPDATE**.
4. Select **ON** to activate or **OFF** to deactivate phonebook automatic update.

PHONEBOOK SEARCH

1. Press and hold **AUDIO/SETUP** to open the setup menu.
2. Select **BLUETOOTH**.
3. Select **PHONE BOOK**.
4. Press **ABC SKIP/TA** to activate the alphabet search mode.
5. Select the first letter.
6. Press the skip next button to move along to the second letter.
7. Select the second letter.

   Note: *Press the skip previous button to return to the previous letter.*
8. Press the skip next button to move along to the third letter.
9. Press the menu select control to show all available matches.
10. Select the desired telephone number, and press the menu control to begin the call.