

## INTERIOR LIGHTS



E135671

- OFF position - permanently off.
- Central position - automatic operation.  
When a door is opened the lamps will illuminate for 15 seconds after the door is closed or until the starter switch is turned on.  
The taildoor of a station wagon will also activate the interior lamps.  
**Note:** *If a door remains open while the switch is in automatic position, the lamps will extinguish after approximately eight minutes.*
- ON position - permanently on.