
MANUAL SEATS



1. Lift locking bar for forward and backward adjustment.
2. Lift locking lever for seat back angle adjustment.
3. Squeeze locking collar for head restraint height adjustment.