

## MANUAL TRANSMISSION

- Never attempt to engage reverse gear while the vehicle is in forward motion. This may result in serious transmission damage and costly repairs.
- Do not rest your hand on the gear lever while driving as this may cause premature wear to the gear selector mechanism.
- Do not rest your foot on the clutch pedal.




The transmission consists of a six speed manual gearbox and a high/low range transfer box. A centre differential distributes the drive to the front and rear axles, providing permanent four wheel drive.

## TRANSFER GEARBOX




**High range**

Use for all normal road driving and when off-road driving across dry, level terrain.

**Low range**

Use only when low speed manoeuvring is necessary. Also use for more extreme off-road conditions where progress in high range cannot be maintained. Move back to high range as soon as conditions allow.

**Transfer neutral**

In transfer neutral position, there is no drive to the road wheels. Use this position when the vehicle is towed.