


## ENGINE COMPARTMENT OVERVIEW



E145312

1. Engine oil filler cap (4.4L diesel).
2. Engine oil filler cap (3.0L diesel).
3. Engine oil filler cap (5.0L petrol).
4. Brake fluid reservoir cap.

**Note:** The brake fluid reservoir cap is always located on the driver's side of the vehicle.

5. Windscreen washer fluid filler cap.
6. Dynamic response fluid reservoir cap.
7. Engine coolant filler cap.



**Do not drive if there is a possibility that leaked fluid will come into contact with a hot surface, such as the exhaust.**