At this point, the first time user should set up personal preferences in the **Nav set-up** area. These settings are applied whenever navigation is used.

MAIN MENU

E141771

1. **More…**: Displays the other Nav menu screen.

2. **Cancel guidance**: Cancels current route guidance.

3. **Destination entry**: Provides a choice of options for entering a destination.

4. **Previous destination**: Displays previous destinations entered.

5. **Display/Hide POI**: Turns the POI (Point Of Interest) icons on the map on/off.

6. When a destination is set, the Range Rover logo is replaced by a soft key which enables the last voice instruction to be repeated.

7. **Route voice guidance**: Allows the voice guidance messages to be turned off for the current journey. The soft key is highlighted while voice guidance is enabled.

8. Quick POI shortcuts. This provides the option to quickly enter a destination of a local POI. The categories can be changed in the Navigation setup menu.