CHILD SEAT POSITIONING

Information given within the table is correct at the time of going to press. However, availability of child restraints may change. Please consult your Dealer/Authorised Repairer for the latest recommendation.

Note: The information contained in the following table may not be applicable to all countries. If you are in any doubt regarding the type and fitment of child seats seek advice from your Dealer/Authorised Repairer.



Note: Ages given are approximate. In case of doubt, the child's weight, not age, should be used when considering an appropriate child seat.

Note: The legislation which governs how and where children should be carried when travelling in a vehicle, is subject to change. It is the responsibility of the driver to comply with all regulations in force.

Seating position	Mass group				
	0 = Up to 10 kg (22 lb) 0-9 months	0+ = Up to 13 kg (29 lb) 0-18 months	l = 9-18 kg (20-40 lb) 9 months to 4 years	ll = 15-25 kg (33-55 lb) 4-9 years	III = 25-36 kg (55-80 lb) 8-12 years
Front passenger*	U	U	U	U	U
Rear seats	U	U	U	U	U

 U = Suitable for universal category restraints approved for this mass group.

* Always ensure that the passenger airbag has been disabled before using a child restraint in this seating position. The seat back needs to be adjusted to the fully upright position. If the head restraint has been removed, ensure it is refitted before the seat is used by a passenger.

RECOMMENDED CHILD SEATS

Child size/age	Recommended seat		
Groups 0 and 0+	Britax/Römer Baby Safe Plus		
Group I	Britax/Römer Duo Plus		
Group II and III	Britax/Römer Kid Plus		