TELEPHONE SYSTEM ICONS



Connect. Use to send or accept a call and access last 10 calls list.

Disconnect. Use to end or reject a call.

No phone connected.



Phone signal strength indicator.



Phone battery level indicator.



Bluetooth. Indicates that a Bluetooth® device is connected.



Tick. Indicates that a Bluetooth® device is paired.

Voicemail. Press and hold to dial the stored voicemail number.

Scroll bar up arrow. Use to scroll up lists of detected phones, calls or phonebook entries.

Scroll bar down arrow. Use to scroll down lists of detected phones, calls or phonebook entries.

STEERING WHEEL CONTROLS



- 1. Press to scroll back through received calls, last 10 list and finally to exit list.
- Increase volume when in a call, scroll up a displayed list or number listed for stored contact.
- **3.** Press to scroll to last 10 list and received calls.
- Decrease volume when in a call or scroll down a displayed list or number listed for stored contact.
- Press to answer an incoming call. Press to end a call. Press and release to dial a number/contact. Press and release to access last 10 dialled list. Press and hold to access phonebook list view.

Note: When scrolling through a phonebook or last 10 list, each contact is also displayed in the message centre.