


SURROUND CAMERA SYSTEM



E141435

The camera home page is accessed by using the camera hard key. See **66, TOUCH SCREEN HOME MENU**.

- 1. Enlarge:** To enlarge a camera view, touch the image then touch the **Enlarge** soft key. Any 2 images can be selected and enlarged to view side-by-side on the screen.

When viewing the two images, one of them can be selected to view as a full screen image. It can then be zoomed into and panned around using the magnifier and arrow icons.

- 2. Proximity View:** Touch to select a combination of 3 images from the front and passenger side cameras.

Automatic Proximity View - Japan only: When Drive or Reverse is selected, the forward or rear view will be displayed. Once the vehicle speed exceeds 18 km/h (11 mph) or the return icon is pressed, the camera screen will disappear.

Note: Proximity view can be accessed at any time by touching Proximity View on the Camera home page.

- 3. Special Views:** Touch to display a selection of pre-set views. They are provided to assist with difficult manoeuvres and are:
 - **Kerb view:** Shows views from the 2 side cameras.
 - **Junction view:** Shows views from the 2 front cameras.
 - **Trailer view:** Shows the rear camera view.
- 4. Camera Settings - Japan only:** Touch to access the camera options page. To deactivate the Semi-auto camera functionality select **Off**. The Proximity view is now only accessible by manual activation using the **Proximity View** soft key.
- 5. Tow Assist:** Touch to display trailer guidance set-up screen.
- If the colour of the camera position arrow changes from blue to red, the system has detected that the camera is dirty. Clean the camera as recommended. See **200, CLEANING THE EXTERIOR**.