
EXTERIOR MIRRORS



1. Left mirror adjustment.
2. Right mirror adjustment.

   Note: *The mirrors can be adjusted for up to five minutes when the ignition is switched off, provided the driver's door is not opened.*
3. Press both switches together to fold/unfold the mirrors.

Note: *If the mirrors are manually folded or knocked into the folded position accidentally, the mirror head will be loose. To re-engage the mechanism, fold, then unfold the mirrors using the switches.*

A thermal cut-out which will temporarily disable the powerfold feature if the switches are operated repeatedly.

Powerfold will only operate if the vehicle is stationary, or travelling at 20 km/h (12 mph) or less.



The mirrors can be configured by your Dealer/Authorised Repairer to automatically fold when the vehicle is locked, and unfold when it is unlocked.