PAIRING AND CONNECTING USING THE TOUCH SCREEN

For further information on Bluetooth®, see 103. BLUETOOTH® INFORMATION.

- Switch on your device's Bluetooth® connection. Make sure that it is in Bluetooth® discoverable mode, sometimes referred to as find me mode (see your device's operating instructions for more information).
- 2. Switch on the ignition and ensure the touch screen is active.
- 3. From the Home menu, select Audio/Video, then My Music.
- 4. Touch Bluetooth.
- 5. A menu will appear. Select Change device.
- 6. Select Vehicle to device option.
- Identify your device from the displayed list and select the corresponding Pair and connect option.

Note: If more than 5 devices are detected, it may be necessary to use the scroll bar to see the entire list.

- 8. When prompted, enter the PIN (Personal Identification Number) code into your device. See your device's operating instructions for more information.
- 9. Once your device is paired and connected to the system, a confirmation message will be displayed before switching to the My music,Bluetooth® view.

Note: Due to the duration of a Bluetooth® search, it is advised that the time-out to home screen feature is switched off before attempting to search for Bluetooth® devices. This setting can be changed within Set-up, Screen. Time out home.

LOSS OF CONNECTION

If a loss of connection between the vehicle and the Bluetooth® device occurs, a pop-up is displayed. Select **Reconnect** to automatically restore the connection. A confirmation pop-up will appear before the touch screen reverts to its previous mode.

CHANGING/DISCONNECTING A DEVICE

- 1. From the menu, select Change device.
- Select Disconnect. A confirmation pop-up will appear and then you will be given the option to Search new or select a different device from the list of paired devices.