Vehicle identification

- **8.** Right-hand B pillar Vehicle Identification Number plate (China).
- 9. Inside fuel filler flap Fuel label.
- 10. Engine number:
 - Diesel The number is located on the front of the engine block.
 - Petrol The number is located on the front of the engine block.

It is important that you are familiar with these subjects to ensure that your vehicle and its features are used safely. Using the index at the back of this handbook, refer to the relevant topic for more information.

VEHICLE BUILD DATE PLATE (Australia only)

This is the calendar month and year in which the body and power train assemblies were conjoined and the vehicle was driven from the production line.

The vehicle built date is shown on a the tyre pressure label attached to the right-hand 'B' pillar.