


ELECTRIC SEATS



SL2125

1. Lumbar support adjustment.
2. Backrest adjustment.
3. Head restraint adjustment.
4. Height adjustment.

5. Forward and back adjustment.
6. Cushion angle adjustment.

To adjust the seats, the Smart Key must be inside the vehicle.