

Note: Front wipers will not operate while the hood is open and vehicle speed is below 2 mph (3 km/h).

RAIN SENSOR

NOTICE

Ensure that the wipers are switched off before entering a car wash. If the rain sensitive wipers operate during the car washing process, damage may occur to the wiper mechanism.

The rain sensor is able to detect the presence and amount of rain/dirt/snow on the windshield and automatically activates the windshield wipers accordingly. Static droplets may not be detected on initial start-up, use a single wipe to clear the screen.

To activate the rain sensitivity wipers, move the wiper stalk to the rain sensor position (4). A single wipe will be actioned.

Adjust the rain sensitivity collar (1) as required. Increasing sensitivity while position (4) is selected will action a single wipe.

If a front door is opened while the wipers are operating, the wipers will be disabled. Operation will restart when the door is closed again.

DRIP WIPE

If the drip wipe function is configured, the wipers will operate four seconds after a wash/wipe cycle has finished, to clear any remaining drips from the windshield.

WIPERS WINTER PARK POSITION

The wipers can be set to park in a higher position than normal. This allows the wiper blades to be lifted from the screen to prevent freezing and sticking. The 'Wipers winter park' option can be selected from the settings menu. See **66, VEHICLE INFORMATION AND SETTINGS MENU**.

HEADLAMP WASHERS

The optional headlamp power wash operates automatically with the windshield wash and will operate only if the headlamps are switched on and there is sufficient washer fluid in the reservoir.

Headlamp wash operates every fourth operation of the screen washers, provided the headlamps are still switched on and approximately ten minutes have elapsed since the last headlamp wash.

Switching the headlamps or ignition off and back on again, will reset the cycle.

See **185, WASHER FLUID TOPPING UP**.

Note: *The headlamps are washed alternately to prevent the washer fluid from reducing the light output from both headlamps simultaneously.*

REAR WIPER

If reverse gear is selected while the front wipers are operating, the rear wiper will start automatically and continue as long as reverse gear is selected. The wipe interval is dependent on the front wipers setting.

If reverse gear is selected while the rear wiper control is in the INT position, the wiper will operate for a single sweep of the rear screen.