## Warning lamps

## TRAILER TURN SIGNALS (GREEN)



Illuminates briefly when the ignition is switched on and extinguishes when the engine is

started.

If a trailer is attached, the warning lamp will flash in conjunction with the turn signal warning lamp. If the lamp fails to flash, the signal bulb on the trailer may be faulty.

## **HIGH BEAM ASSIST(GREEN)**



Illuminates when the High beam assist feature is enabled.

## **HIGH BEAM (BLUE)**



Illuminates when the high beam headlamps are switched on or flashed.