


## MAIN MENU



E141771

### **⚠ WARNING**

**Do not adjust the touch screen controls, or allow the system to distract the driver, while the vehicle is moving. Driver distraction can lead to accidents, causing serious injury or death.**

1. **More...:** Displays the other Nav menu screen.
2. **Cancel guidance:** Cancels current route guidance.
3. **Destination entry:** Provides a choice of options for entering a destination.
4. **Previous destination:** Displays previous destinations entered.
5. **Display/Hide POI:** Turns the POI (Point Of Interest) icons on the map on/off.
6. When a destination is set, the Range Rover logo is replaced by a soft key which enables the last voice instruction to be repeated.
7. **Route voice guidance:** Allows the voice guidance messages to be turned off for the current trip. The soft key is highlighted while voice guidance is enabled.
8. **Quick POI shortcuts.** This provides the option to quickly enter a destination of a local POI. The categories can be changed in the Navigation setup menu.
9. **Return to map:** Advances to the main map screen.
10. **Return to map:** Advances to the main map screen.
11. **Nav set-up:** Advances to the Navigation setup menu.
12. **Route options:** Displays route options.
13. **TMC:** Displays Traffic Message Channel information.
14. **Stored locations:** Displays stored locations.