

### LOCKING AND ARMING THE ALARM.

#### **⚠ WARNING**

Before exiting the vehicle, always ensure that the gear selector is in the Park (P) position, the engine is turned off, the parking brake is applied and the Smart Key is removed from the vehicle.

#### **NOTICE**

*No modifications or additions should be made to the anti-theft system. Such changes could cause the system to malfunction.*

With all doors and tailgate closed, press the lock button on the Smart Key once, to lock the vehicle and activate the perimeter alarm. The alarm LED in the instrument panel will start to flash and the hazard warning lamps will flash once to confirm locking. Power fold mirrors will fold in (if enabled). This secures the vehicle and prevents the doors from being opened from outside. The doors may still be unlocked and opened using the interior door locks and release levers. When the vehicle is locked and the alarm is armed, the alarm will sound if the hood, tailgate or a door is opened.

#### **NOTICE**

*The vehicle will not lock if a door, the tailgate or the hood is open, or the ignition is ON. No lamps will flash and if the lock request is via the Smart Key, there will be an audible mislock warning.*

#### **NOTICE**

*Ensure that the Smart Key does NOT remain in the vehicle prior to closure. If the vehicle is in an area of localised RF interference or the Smart Key is shielded by metal objects, the vehicle may close and lock with no means of opening again.*

#### **NOTICE**

*Remove any additional Smart Keys from the vehicle before locking.*

### AUTOMATIC RELOCKING AND RE-ARMING OF THE ALARM

If a door, tailgate or hood are not opened within 40 seconds of unlocking the vehicle via the Smart Key, all doors will re-lock automatically to the previous locked state and the alarm will re-arm.

### LOCK CONFIRMATION

If you are uncertain whether the vehicle is locked and armed, press either the Smart Key lock button or, if Keyless entry is fitted, touch an exterior door handle lock sensor. The hazard warning lamps will flash once to indicate and confirm the current lock status..

**Note:** *If the vehicle is **not** already locked and armed, pressing the lock button will lock the vehicle.*

### MISLOCK

When locking the vehicle with the Smart Key, if one or more of the doors, the hood or the tailgate is not fully closed, or the ignition is ON, the vehicle will NOT lock and there will be an audible mislock error warning. The hazard warning lamps will NOT flash and the door mirrors (if enabled) will NOT fold in. Check that all doors, the hood and the tailgate are closed properly. Ensure the ignition is turned OFF and lock the vehicle again. If the mislock persists, consult a Land Rover Retailer.