

7. **Settings.** Select to view the Settings menu:

- **Options:** To activate/deactivate Song seek and to view and edit the Song memory.
- **Channel skip:** Select individual channels or entire categories (select **Skip all**) from the list. The selected channels/categories will be skipped when using the Seek controls.
- **Parental lock:** Select individual channels or entire categories (**Lock all**) from the list. Locked channels/categories cannot be selected without first entering the correct PIN. A 4-digit PIN needs to be entered to access the parental lock area. The default PIN is "0000" Select Edit PIN to change the PIN.

***Note:** If the PIN is forgotten, it can be reset by touching and holding Parental lock for 10 seconds, then touching and holding SAT information for 10 seconds.*

- **SAT information:** Select to view your SIRIUS ID number and subscription contact number.

8. **Channel list:** Touch to view a list of available categories. Select the desired category to view the list of corresponding channels. Make your channel selection from the list.

9. **Channel input:** Select to use the numerical touch-pad to enter a channel number. The **OK** soft key can be used at any time to enter your selection. If a single number, e.g. 7, is entered, SDARS will tune to that channel.

If 07 or 007 is entered, SDARS will still tune to the same channel. If **OK** is not touched after numbers are selected, the station will automatically tune to that station following a time out period.

10. **Browse:** Select from the list of categories to view the details (channel number, artist and title of current track) of the channels in the selected category.

***Note:** If there is more information than can fit on the display, select **i** to view all the information available.*

Select a channel from the list to tune to that channel (list is still displayed for further browsing).

11. **Add song:** Select to add the currently playing song title to the song memory.

Subsequently, if a subscribed channel is broadcasting a song and its title is stored in the song memory, a pop-up will be displayed giving you the option to tune to that channel .

If the song memory is full and the vehicle is stationary, the option to edit the memory is available on a pop-up screen. Existing song titles can be deleted from the memory, allowing alternative song titles to be stored.

SIRIUS SUBSCRIPTION

Channel 184 (The Weather Channel) is available as a preview channel for a limited time only. Once the preview has expired, or to receive further satellite radio stations, you will need to subscribe to SIRIUS.

Ensure your vehicle is parked in a position with a clear view to the sky above the vehicle antenna.

From inside your vehicle, call the Sirius Call Center using the toll free number displayed in **Settings/SAT Information**. The SIRIUS ID number is also displayed here. You must have your credit card available and it must be registered to a US or Canadian postal address.