


TELEPHONE SYSTEM OVERVIEW



SL1857

⚠ WARNING

Do not adjust the touch screen controls, or allow the system to distract the driver, while the vehicle is moving. Driver distraction can lead to accidents, causing serious injury or death.

- 1. Change phone.** Touch to search new or change to another paired phone.
- 2. Last 10.** Select to access the last 10 dialed, received and missed calls.
- 3. Phonebook.** Select to access the downloaded phonebook.
- 4. Digit Dial.** Select to access Digit Dial mode.
- 5.** Touch and hold soft key 1 retrieve your Voice mail.
- 6.** Status display. Displays the name and/or number dialed and call duration.
- 7.** Call Connect/Disconnect icons. Touch to send/accept or end/reject a call.
- 8. Settings.** Access Voice mail set up, Answer options and Phone options.
- 9. Mute microphone.** Select to initiate Privacy mode. While selected, the caller will not hear you talking.
- 10.** Touch to activate/deactivate Auto reject. When active, any incoming calls will be rejected or diverted to voice mail (depending on cell phone settings).
- 11. Use handset.** Select to switch the call to your cell phone.
- 12. Delete.** Touch and release to delete the last entered digit. Touch and hold to delete the whole entered number.