
## MAIN MENU



- **1. More...**: Displays the other Nav menu screen.
- 2. Cancel guidance: Cancels current route guidance.
- **3. Destination entry**: Provides a choice of options for entering a destination.
- **4. Previous destination**: Displays previous destinations entered.
- **5. Display/Hide POI**: Turns the POI (Point Of Interest) icons on the map on/off.
- When a destination is set, a soft key is displayed, which enables the last voice instruction to be repeated.

- 7. Route voice guidance: Allows the voice guidance messages to be turned off for the current journey. The soft key is highlighted while voice guidance is enabled.
- 8. Quick POI shortcuts. This provides the option to quickly enter a destination of a local POI. The categories can be changed in the Navigation setup menu.
- **9. Return to map**: Advances to the main map screen.
- **10. Detour**: Allows a detour from the current route.
- **11. Nav set-up**: Settings for the navigation system.
- **12. Route options**: Allows selection of various options for the route.