
MANUAL SEATS



 \triangle

Do not adjust the seat while the vehicle is moving. Doing so could cause loss of vehicle control and personal injury.

- 1. Forward and rearward adjustment.
- 2. Height adjustment.
- 3. Backrest adjustment.
- 4. Lumbar support adjustment.
- 5. Armrest height adjustment.