
USING VOICE CONTROL



Say a command...

Re st Phone
st Navigation
st USB
st CD / CD Changer
st Radio
st D.A.B.

User 1
Re st Help
st Cancel

E142207

Note: The voice system has been designed to recognise a number of languages. However, Land Rover cannot guarantee the system will be compatible with every accent group within those languages. Please speak to your Dealer/Authorised Repairer about testing the Voice System for compatibility with a particular accent group.

 Voice button: Press briefly to start a voice session. A pop up will appear on the touch screen. Press and hold to cancel a voice session.

Note: Briefly press the Voice button during a voice session, to interrupt audible feedback. Wait for the tone to sound before giving the next command.

- Voice symbol: Indicates that a command is available. Wait for the symbol to appear and a tone to sound before using the command.
- Command list: Appears on the pop up panel, providing feedback and available commands at each stage of the voice session. Say an available command.

Note: As the commands are listed before the system is ready to listen, it is important to wait for the voice symbol to appear alongside the relevant command, before using the command.

- **4.** When displayed, say **Cancel** to cancel the current voice session.
- **5.** When displayed, say **Help** to get assistance during a voice session.

Note: The currently selected user (User 1 or User 2) is identified at the bottom of the command list.

Note: If a listed item is longer than the available space on the menu, ...> will appear. Use the seek controls on the steering wheel to view the entire entry. See 117, AUDIO/VIDEO CONTROLS.