
AIRBAGS



E134921

- 1. 3rd row seats, curtain airbag.
- 2. Main curtain airbag.
- 3. Side airbags.
- **4.** Driver's front and side airbags.
- 5. Passenger front and side airbags.
- Passenger airbag disable switch location, see 36, DISABLING THE PASSENGER AIRBAG.
- 7. Passenger airbag warning label.
- 8. Passenger airbag disable switch operation.

Note: The general location of airbags fitted to the vehicle are marked by the word AIRBAG.

Always contact your Dealer/Authorised Repairer if:

- · An airbag inflates.
- The front or sides of the vehicle are damaged.
- Any part of the Airbag Supplementary Restraint System (SRS) shows signs of cracking or damage, including trim covering airbags.