
Navigation system

- **13. TMC** (Traffic Message Channel): Not used for entering a destination but, when enabled, will provide data about road conditions and any events that may affect the journey.
- **14. Stored locations**: Manages the stored locations.

MAP SPLIT SCREEN



- 1. Compass (always indicates North). Press to select: North up, heading up or bird's eye map style.
- 2. TMC (Traffic Message Channel) signal. Without a diagonal bar, a signal is being received; with a diagonal bar, a signal is not being received. The icon will also change colour depending on the status of traffic on the route.
- 3. Next direction display. When intersection map view has been switched off, touch icon to view again.
- 4. Current vehicle position and direction.
- 5. Right map view, scale/zoom setting.

- 6. Current location.
- 7. GPS signal indicator. The indicator is only displayed when there is no reception.
- 8. Screen selection.
- **9.** Left map view, scale/zoom setting.
- **10.** Opens Navigation menu 1 of 2 screens.
- 11. Distance/time to destination.
- **12.** TMC event (traffic congestion).



Touch to close the Intersection and Motorway junction view. The previously displayed map is shown after closing.