


13. TMC (Traffic Message Channel): Not used for entering a destination but, when enabled, will provide data about road conditions and any events that may affect the journey.

14. Stored locations: Manages the stored locations.

MAP SPLIT SCREEN



E141772

1. Compass (always indicates North). Press to select: North up, heading up or bird's eye map style.
2. TMC (Traffic Message Channel) signal. Without a diagonal bar, a signal is being received; with a diagonal bar, a signal is not being received. The icon will also change colour depending on the status of traffic on the route.
3. Next direction display. When intersection map view has been switched off, touch icon to view again.
4. Current vehicle position and direction.
5. Right map view, scale/zoom setting.
6. Current location.
7. GPS signal indicator. The indicator is only displayed when there is no reception.
8. Screen selection.
9. Left map view, scale/zoom setting.
10. Opens Navigation menu 1 of 2 screens.
11. Distance/time to destination.
12. TMC event (traffic congestion).



Touch to close the Intersection and Motorway junction view. The previously displayed map is shown after closing.