## Entering the vehicle

#### SMART KEY TRANSMITTERS

### AWARNING


Any person fitted with an implanted medical device should be kept at a distance of at least 8.7 inches (22 cm) away from any transmitter mounted in the vehicle. This is to avoid any possibility of interference between the system and the device. Interference may cause the implanted medical device to malfunction, causing serious injury or death. For information concerning the location of the security system transmitters, see 183, SMART KEY TRANSMITTER LOCATIONS.

#### DRIVE-AWAY LOCKING

Drive-away locking automatically locks all the doors when the vehicle is in motion. This feature can be enabled/disabled via the Vehicle Set-up menu, see **62**, **INSTRUMENT PANEL MENU**.

**Note:** Pressing the lock or unlock button on the Smart Key will override Drive-away locking for the current journey.

# OPENING AND CLOSING THE TAIL GATE



## NOTICE

Ensure there is minimum space of 39 in. (1 meter) above the rear of vehicle before operating the tailgate. Insufficient space may result in damage to the vehicle.

## NOTICE

Do not operate the tailgate if a cycle rack is fitted to the tailgate. Remove any cycles and/or racks before operating the tailgate.

**Upper tailgate:** Unlock the vehicle and press the touchpad (1) on the underside of the exterior handle. Pull the tailgate upwards to open.

**Lower tailgate:** With the upper tailgate open, press the touchpad on the lower tailgate waist moulding (2). Lower the tailgate to open.