


ENGINE COMPARTMENT OVERVIEW



1135499

1. Brake fluid reservoir cap.
2. Engine oil filler cap.
3. Engine coolant filler cap.
4. Windshield washer fluid filler cap.
5. Power steering fluid filler cap.

⚠ WARNING

While working in the engine compartment, always observe the safety precautions. See 157, SAFETY IN THE GARAGE.

⚠ WARNING

Do not drive if there is a possibility that leaked fluid will come into contact with a hot surface, such as the exhaust.