


SMART KEY BATTERY REPLACEMENT

When the battery needs renewing, there will be a significant decrease in the effective range and the message **SMART KEY BATTERY LOW** will be displayed in the message center.



Battery disposal: Used batteries must be disposed of correctly, as they contain harmful substances.

Seek advice on disposal from your Land Rover Retailer/Authorized Repairer and/or your local authority.



E135421

To renew the battery:

1. Slide the cover in the direction of the arrow until a click is heard. remove the cover.
2. Use the emergency key blade to separate the Smart Key body.
3. Fit a new CR2032 type battery (available from your Land Rover Retailer/Authorized Repairer), with the positive (+) side upwards.

Note: Avoid touching the new battery, as moisture/oil from fingers can reduce battery life and corrode the contacts.

Refit the parts in reverse order, ensuring that they click securely into place.