

DRIVER CONTROLS

1. Map reading lamp switch (47).
2. Main interior lamp switch (47).
3. Sunroof close switch (50).
4. Sunroof open switch (50).
5. High beam/Direction indicator/Trip computer switch (45/63).
6. Audio system control (106).
7. Instrument panel and message center (61).
8. Vehicle information menu control (62).
9. Wiper/washer controls (48).
10. START/STOP button (78).
11. Audio system and controls (106).
12. Touch screen (103).
13. Left hand heated seat switch (65).
14. Stability control off switch (84).
15. Hazard warning light control switch.
16. Parking aid switch (94).
17. Right hand heated seat switch (65).
18. Heater/air conditioning control (65).
19. Electric parking brake (89).
20. Air suspension control (85).
21. Hill descent control (HDC) switch (101).
22. Transfer gearbox switch (82).
23. Terrain response switch (99).
24. Heated steering wheel switch (27).
25. Voice recognition and telephone switches (130/136).
26. Horn switches.
27. Cruise control switches (96).
28. Electric mirror controls (52).
29. Electric window controls (50).
30. Electric window rear isolator switch (50).
31. Rear fog lamp switch (45).
32. Front fog lamp switch (45).
33. Instrument illumination dimmer control (45).
34. Main exterior lamp control (45).

