

**A**

ABS (Anti-lock braking system)	
warning lamp . . . . .	69
ACC	
follow mode . . . . .	69
ACC (Adaptive cruise control) . . . . .	128
automatic switch-off . . . . .	130
driving hints . . . . .	131
fault . . . . .	132
follow mode . . . . .	129
gap change . . . . .	129
malfunction . . . . .	132
operating . . . . .	128
override . . . . .	130
resume follow mode . . . . .	130
resume set speed . . . . .	130
Adaptive front lighting system (AFS)	
warning lamp . . . . .	69
AFS (Adaptive front lighting system) . . . . .	50
Air bags . . . . .	43
deployment effects . . . . .	46
disability modifications . . . . .	48
front . . . . .	43
module covers . . . . .	199
occupant sensing . . . . .	46
operation . . . . .	44
service information . . . . .	47
side and curtain . . . . .	44
SRS (Supplementary restraint system) . . . . .	191
warning lamp . . . . .	46
warning lamps . . . . .	69
Air conditioning	
air quality sensor . . . . .	81
rear . . . . .	84
Air quality sensor . . . . .	81
Alarm	
deactivating . . . . .	17
Antifreeze level check . . . . .	203
Anti-trap protection	
windows . . . . .	57
Arduous driving conditions . . . . .	192
ASL (Automatic speed limiter)	
warning lamp . . . . .	69

Audio	
Settings . . . . .	143
Audio/video	
controls . . . . .	142
portable media	
connections . . . . .	156
controls . . . . .	154
pairing . . . . .	158
play . . . . .	158
video media player	
controls . . . . .	160
Automatic gearbox . . . . .	104
Automatic locking . . . . .	12
Automatic switch off (ACC) . . . . .	130
Auxiliary devices	
connecting multiple devices . . . . .	158
<b>B</b>	
Battery	
changing	
timed climate remote . . . . .	232
charging . . . . .	231
jump starting	
connecting cables . . . . .	228
vehicle	
removing . . . . .	230
warning symbols . . . . .	228
Beltminder	
warning lamp . . . . .	68
Belts . . . . .	199
seatbelt warning lamp . . . . .	68

# Index

- Bluetooth . . . . . 168
  - audio . . . . . 168
    - pairing . . . . . 158
  - media . . . . . 158
    - pairing . . . . . 158
  - telephone . . . . . 169
    - compatibility . . . . . 171
    - icons . . . . . 171
    - overview . . . . . 168
    - pairing . . . . . 170
    - phonebook . . . . . 172
    - safety . . . . . 169
- Boost starting . . . . . 228
- Brakes
  - ABS warning lamp . . . . . 69
  - advanced emergency assist . . . . . 133
  - EBA (Emergency brake assist) . . . . . 114
  - EBD (Electronic brake force distribution) . . . . . 114
  - handbrake . . . . . 115
  - parking brake
    - warning lamp . . . . . 68
  - warning lamp . . . . . 67
- BSM (Blind spot monitor) . . . . . 60
- C**
  - Call volume . . . . . 172
  - Capacities . . . . . 209
  - Chairs
    - massage . . . . . 83
    - massage chairs . . . . . 83
    - restricted seat travel . . . . . 20
    - seatbelts . . . . . 199
      - warning lamp . . . . . 68
    - sitting correctly . . . . . 20
  - Changing a bulb . . . . . 195
  - Changing a fuse . . . . . 234
  - Changing the battery (timed climate) . . . . . 232
  - Charging the vehicle battery . . . . . 231
  - Cleaning
    - exterior . . . . . 197
    - interior . . . . . 198
    - leather . . . . . 199
    - parking sensors . . . . . 118
  - Climate control
    - rear . . . . . 84
  - Climate seats . . . . . 81
  - Closing the hood . . . . . 193
  - Condensation (headlamps) . . . . . 51
  - Controls
    - headlamps . . . . . 49
  - Coolant
    - checking the level . . . . . 203
    - specification . . . . . 203
    - top up . . . . . 203
  - Critical warning messages . . . . . 67
  - Cruise control
    - ACC (Adaptive cruise control) . . . . . 128
      - malfunction . . . . . 132
      - operating . . . . . 128
      - override . . . . . 130
      - resume follow mode . . . . . 130
      - resume set speed . . . . . 130
    - follow mode . . . . . 129
    - operating . . . . . 126
- D**
  - Daily checks . . . . . 192
  - Data recording . . . . . 251
  - Deselecting valet mode . . . . . 78
  - Destination entry . . . . . 178
    - search area . . . . . 178
  - Detection beam issues . . . . . 131
  - Diesel
    - engine
      - switching off . . . . . 101
  - Dimensions . . . . . 211
  - Disability modifications (air bags) . . . . . 48
  - Door transceiver
    - entry gate . . . . . 66
    - garage door opener . . . . . 64

- Drive away locking . . . . . 12
  - Driver controls . . . . . 266
  - Driver information module
    - warning lamps . . . . . 67
  - Driving
    - ACC (Adaptive cruise control) . . . 128, 131
      - override . . . . . 130
    - adaptive cruise control
      - automatic switch off . . . . . 130
    - arduous conditions . . . . . 192
    - before starting . . . . . 251
    - controls . . . . . 266
    - daily checks . . . . . 192
    - DSC warning lamp
      - active . . . . . 68
      - off . . . . . 69
    - EBA (Emergency brake assist) . . . . . 114
    - EBD (Electronic brake force distribution) . . . 114
      - forward alert . . . . . 132
        - warning lamp . . . . . 70
      - mirror dip when reversing . . . . . 59
      - sitting correctly . . . . . 20
      - wipers
        - rain sensor . . . . . 55
  - DSC (Dynamic stability control)
    - switching off . . . . . 108
    - switching on . . . . . 108
    - warning lamp
      - active . . . . . 68
      - off . . . . . 69
- E**
- EBA (Emergency brake assist) . . . . . 114
  - EBD (Electronic brake force distribution) 114
  - Electric seats
    - front . . . . . 19
    - rear . . . . . 23
  - Electronic brake force distribution (EBD) 114
  - Electronic data . . . . . 251
  - Electronic parking brake (EPB) . . . . . 115
  - Emergency
    - jump starting
      - connecting cables . . . . . 228
  - Emergency brake assist (EBA) . . . . . 133
  - Engine
    - compartment
      - fuse box . . . . . 235
      - opening . . . . . 193
      - overview . . . . . 194
    - coolant level checking . . . . . 203
    - engine compartment . . . . . 194
    - failure to start . . . . . 102
    - oil level check . . . . . 201
    - specifications . . . . . 208
    - switching off . . . . . 101
  - Entering a destination . . . . . 178
  - Entering the vehicle
    - entry and exit mode . . . . . 29
    - keyless entry . . . . . 11

# Index

- Entertainment
  - navigation
    - coordinates . . . . . 181
    - menu . . . . . 175
    - POI categories . . . . . 182
    - POI (Points of interest) . . . . . 180, 181
    - previous . . . . . 181
    - restore defaults . . . . . 180
    - TMC . . . . . 182
    - TMC display . . . . . 182
    - TMC icons . . . . . 183
  - portable media
    - changing device . . . . . 159
    - connecting devices . . . . . 157
    - connecting multiple devices . . . . . 158
    - connections . . . . . 156
    - controls . . . . . 154
    - lost connection . . . . . 159
    - pairing . . . . . 158
    - playing . . . . . 158
  - radio
    - controls . . . . . 148
    - RBDS (Radio broadcast data system) . . . . . 149
  - RSE (Rear screen entertainment)
    - screen settings . . . . . 77
  - satellite radio
    - controls . . . . . 151
  - telephone
    - pairing . . . . . 170
    - phonebook . . . . . 172
  - touch screen . . . . . 200
    - home menu . . . . . 76
    - operating . . . . . 77
    - setup . . . . . 77
    - system settings . . . . . 77
    - touch screen care . . . . . 77
  - video media player
    - controls . . . . . 160
- Entry and exit mode . . . . . 29
- EPB (Electric parking brake) . . . . . 115
- Event data recording . . . . . 251
- Exiting the vehicle
  - door locks and release levers . . . . . 17
  - keyless locking . . . . . 16
- Exterior cleaning . . . . . 197
- Exterior lamps
  - bulb changing . . . . . 195
- Exterior mirrors . . . . . 58
- EZ toll card . . . . . 57
- F**
  - Flat spots . . . . . 223
  - Fluids
    - capacities . . . . . 209
    - coolant
      - specification . . . . . 203
      - top up . . . . . 203
    - engine oil
      - check . . . . . 201
    - specifications . . . . . 208
    - washer
      - specification . . . . . 206
      - top up . . . . . 206
  - Fog lamps
    - warning lamp . . . . . 69
  - Follow mode . . . . . 69
    - entering . . . . . 129
    - gap change . . . . . 129
    - override . . . . . 130
    - resume . . . . . 130
  - Forward alert . . . . . 132
  - Forward alert warning lamp . . . . . 70
  - Front parking aid . . . . . 117
    - system fault . . . . . 118
  - Fuel and refuelling
    - fuel system . . . . . 193
  - Fuses
    - changing . . . . . 234
    - engine compartment fuse box . . . . . 235
    - locations . . . . . 233
    - luggage compartment fuse box . . . . . 239
    - Passenger compartment fuse box . . . . . 236

**G**

Garage door opener . . . . .	64
entry gate . . . . .	66
Gearbox	
automatic . . . . .	104
limp home mode . . . . .	107
temporary manual selection . . . . .	106
Global opening . . . . .	11

**H**

Hand brake	
warning lamp . . . . .	68
Handbrake . . . . .	115
Handling	
DSC warning lamp	
active . . . . .	68
off . . . . .	69
EBD (Electronic brake force distribution) . . . . .	114
Headlamps	
adaptive . . . . .	50
AFS (Adaptive front lighting system) . . . . .	50
bulb changing . . . . .	195
condensation . . . . .	51
controls . . . . .	49
high beam warning lamp . . . . .	70
warning lamp (AFS) . . . . .	69
washers . . . . .	55
Heating and ventilation	
rear . . . . .	84
High beam	
warning lamp . . . . .	70
Homelink . . . . .	64
Hood	
closing . . . . .	193
opening . . . . .	193

**I**

Ignition	
rolling re-start . . . . .	102
switching on . . . . .	101
Information messages . . . . .	67

**Infotainment**

navigation	
coordinates . . . . .	181
menu . . . . .	175
POI categories . . . . .	182
POI (Points of interest) . . . . .	180, 181
previous . . . . .	181
restore defaults . . . . .	180
TMC . . . . .	182
TMC display . . . . .	182
TMC icons . . . . .	183
portable media	
changing device . . . . .	159
connecting devices . . . . .	157
connecting multiple devices . . . . .	158
connections . . . . .	156
controls . . . . .	154
lost connection . . . . .	159
pairing . . . . .	158
playing . . . . .	158
radio	
controls . . . . .	148
RBDS (Radio broadcast data system) . . . . .	149
RSE (Rear seat entertainment)	
screen settings . . . . .	77
satellite radio	
controls . . . . .	151
telephone	
pairing . . . . .	170
phonebook . . . . .	172
touch screen . . . . .	200
home menu . . . . .	76
operating . . . . .	77
setup . . . . .	77
system settings . . . . .	77
touch screen care . . . . .	77
video media player	
controls . . . . .	160
Inhibited media playback . . . . .	161
Instrument panel	
lamp test . . . . .	67
warning lamps . . . . .	67

# Index

Interior cleaning .....	198
Interior lamps	
bulb changing .....	195
<b>J</b>	
Jump starting .....	228
<b>K</b>	
Keyless entry .....	11
Keyless locking .....	16
Keys	
smart key transmitters .....	12
<b>L</b>	
Lamp test .....	67
Lamps	
bulb changing .....	195
condensation .....	51
controls .....	49
warning	
parking brake .....	68
warning lamps .....	67
TPMS (Tire pressure monitoring system)	
70	
Leather cleaning .....	199
Lights	
bulb changing .....	195
condensation .....	51
controls .....	49
Limp home mode .....	107
Locking	
door locks and release levers .....	17
drive away .....	12
keyless .....	16
mislock .....	17
Locking and unlocking	
unlocking .....	9
Lubricants	
specifications .....	208
Luggage compartment	
fuse box .....	239

## M

Maintenance	
blocked washer jets .....	195
bulb changing .....	195
capacities .....	209
changing a fuse .....	234
cleaning parking sensors .....	118
closing the hood .....	193
coolant level checking .....	203
daily checks .....	192
engine compartment .....	194
exterior cleaning .....	197
fuse box (luggage compartment) .....	239
interior cleaning .....	198
jump starting	
connecting cables .....	228
leather cleaning .....	199
lubricants and fluid specifications .....	208
smart key battery changing .....	15
weekly checks .....	192
Map (navigation system) .....	181
Map split screen (navigation system) .....	177
Massage seats .....	83
Media .....	161
inhibited .....	161
portable	
lost connection .....	159
play .....	158
portable media	
connections .....	156
Messages .....	67
Mirrors	
BSM (Blind spot monitor) .....	60
dip when reversing .....	59
Mirrors and windows	
exterior mirrors .....	58
sunroof	
reset .....	196
Moon roof	
reset .....	196

**N**

## Navigation

cancel guidance . . . . .	180
destination entry . . . . .	178
coordinates . . . . .	181
emergency . . . . .	181
previous . . . . .	181
search area . . . . .	178
start guidance . . . . .	179
map . . . . .	181
map split screen . . . . .	177
menu . . . . .	175
operating . . . . .	174
overview . . . . .	173
POI (Points of interest) . . . . .	181
categories/sub-categories . . . . .	182
quick POI selection . . . . .	180
POI search . . . . .	182
restore defaults . . . . .	180
screen modes . . . . .	178
TMC . . . . .	182
display . . . . .	182
icons . . . . .	183
using TMC . . . . .	184
voice commands (POI) . . . . .	167
voice guidance . . . . .	180

**O**

## Occupant safety

seatbelts . . . . .	199
warning lamp . . . . .	68

## Oil

engine	
level check . . . . .	201
engine oil specification . . . . .	202
used engine oil . . . . .	193

## Opening the hood . . . . . 193

## Overriding speed and follow mode (cruise) . . . . . 130

**P**

## Paddle shift

temporary manual selection . . . . .	106
--------------------------------------	-----

## Parking aid

operating . . . . .	117
sensor cleaning . . . . .	118
system fault . . . . .	118

## Parking brake . . . . . 115

warning lamp . . . . .	68
------------------------	----

## Passenger compartment fuse box . . . . . 236

## Petrol

engine	
switching off . . . . .	101

## Phone

bluetooth . . . . .	168
call volume . . . . .	172
changing connected phone . . . . .	171
compatibility . . . . .	169
controls	
steering wheel . . . . .	171
icons . . . . .	171
overview . . . . .	168
pairing using touch screen . . . . .	170
phonebook . . . . .	172
safety . . . . .	169

## POI (Points of interest) . . . . . 181

search . . . . .	182
------------------	-----

## Portable media

changing device . . . . .	159
connecting devices . . . . .	157
connecting multiple devices . . . . .	158
connections . . . . .	156
controls . . . . .	154
lost connection . . . . .	159
pairing . . . . .	158
playing . . . . .	158

## Previous destination (navigation system) . 181

## Punctured tires . . . . . 223

## R

Radio	
controls	148
RBDS (Radio broadcast data system)	149
Rain sensor	55
RBDS (Radio broadcast data system)	149
RBDS-TMC	182
display	182
icons	183
RDS-TMC	184
Rear media	
screen settings	77
Recording	
service data	251
Recovery	
towing eyes	246
transporting	248
Remote control	
battery changing	15
system transmitters	213
Removing vehicle battery	230
Replacement tires	223
Reporting safety defects	8
Resetting the windows	196
Restarting the engine whilst moving	102
Restore default settings (navigation system)	180
Restricted seat travel	20
Resume speed and follow mode (ACC)	130
Reverse parking aid	117
system fault	118
Rolling re-start	102
RSE (Rear seat entertainment)	
screen settings	77

## S

Safety	
air bag deployment effects	46
air bag operation	44
air bag service information	47
air bags	43
disability modifications (air bags)	48
in the garage	192
seatbelts	199
warning lamp	68
sitting correctly	20
smart key transmitter locations	12
used engine oil	193
using the telephone	169
Safety defects	8
Safety precautions	
tire care	219
Satellite navigation	
cancel guidance	180
destination entry	178
coordinates	181
previous	181
search area	178
start guidance	179
emergency	181
map	181
map split screen	177
menu	175
operating	174
overview	173
POI (Points of interest)	181
categories	182
quick POI selection	180
POI search	182
restore defaults	180
screen modes	178
TMC	182
display	182
icons	183
using TMC	184
voice commands (POI)	167
voice guidance	180

- Satellite radio
    - controls . . . . . 151
  - Screen modes (navigation system) . . . . . 178
  - Search area (navigation system) . . . . . 178
  - Seatbelts . . . . . 199
    - warning lamp . . . . . 68
  - Seats
    - climate . . . . . 81
    - electric
      - front . . . . . 19
      - rear . . . . . 23
    - restricted seat travel . . . . . 20
    - seat massage . . . . . 83
    - seatbelts . . . . . 199
      - warning lamp . . . . . 68
    - sitting correctly . . . . . 20
  - Security
    - deactivating the alarm . . . . . 17
  - Selecting valet mode . . . . . 78
  - Servicing
    - data recording . . . . . 251
  - Setting a destination (navigation) . . . . . 178
  - Settings
    - rear media . . . . . 77
  - Silencing the alarm . . . . . 17
  - Sitting correctly . . . . . 20
  - Smart key
    - battery changing . . . . . 15
    - transmitters . . . . . 12, 213
  - Specifications
    - dimensions . . . . . 211
    - engine . . . . . 208
    - fluids . . . . . 208
      - washer . . . . . 206
    - lubricants . . . . . 208
    - weight . . . . . 210
  - Speed-dependent wipers . . . . . 55
  - Split screen map . . . . . 177
  - SRS (Supplementary restraint system)
    - air bag covers . . . . . 199
    - air bag warning lamp . . . . . 69
    - air bags . . . . . 191
  - Stability control
    - switching off . . . . . 108
    - switching on . . . . . 108
  - Starting
    - preparation . . . . . 251
  - Starting navigation guidance . . . . . 179
  - Steering wheel
    - adjusting . . . . . 29
    - controls
      - connect phone call . . . . . 171
      - decrease volume . . . . . 171
      - disconnect phone call . . . . . 171
      - increase volume . . . . . 171
      - scroll/search down . . . . . 171
      - voice control talk . . . . . 171
  - Steering wheel controls . . . . . 171
  - Storage compartments . . . . . 94
    - cup holders . . . . . 94
    - front cubby box . . . . . 94
    - glove box . . . . . 94
    - rear armrest . . . . . 94
  - Sunroof
    - reset . . . . . 196
  - Switching off the engine . . . . . 101
  - Switching on the ignition . . . . . 101
- ## T
- Technical specifications
    - weights . . . . . 210
  - Telephone
    - bluetooth . . . . . 168
    - call volume . . . . . 172
    - changing the connected telephone . . . . . 171
    - compatibility . . . . . 169
    - controls
      - steering wheel . . . . . 171
    - icons . . . . . 171
    - overview . . . . . 168
    - pairing . . . . . 170
    - phonebook . . . . . 172
    - safety . . . . . 169

# Index

- Tires
  - flat spots . . . . . 223
  - punctured . . . . . 223
  - replacements . . . . . 223
  - tire care . . . . . 219
  - TPMS (Tire pressure monitoring system)
    - warning lamp . . . . . 70
  - valves . . . . . 223
- TMC . . . . . 182
  - display . . . . . 182
  - icons . . . . . 183
- TMC (Traffic message channel) . . . . . 184
- Toll card fixing . . . . . 57
- Touch screen . . . . . 200
  - home menu . . . . . 76
  - navigation
    - coordinates . . . . . 181
    - menu . . . . . 175
    - POI categories . . . . . 182
    - POI (Points of interest) . . . . . 180, 181
    - screen modes . . . . . 178
    - search area . . . . . 178
    - TMC . . . . . 182
    - TMC icons . . . . . 183
  - operating . . . . . 77
  - portable media
    - changing device . . . . . 159
    - connecting devices . . . . . 157
    - connecting multiple devices . . . . . 158
    - connections . . . . . 156
    - controls . . . . . 154
    - lost connection . . . . . 159
    - pairing . . . . . 158
    - playing . . . . . 158
  - RSE (Rear seat entertainment)
    - screen settings . . . . . 77
  - setup . . . . . 77
  - system settings . . . . . 77
  - telephone
    - pairing . . . . . 170
    - phonebook . . . . . 172
  - touch screen care . . . . . 77
  - valet mode . . . . . 78
  - video media player
    - controls . . . . . 160
- Towing eyes . . . . . 246
- TPMS (Tire pressure monitoring system)
  - tire care . . . . . 219
  - valves . . . . . 223
  - warning lamp . . . . . 70
- Traction control
  - switching off . . . . . 108
  - switching on . . . . . 108
- Transmission
  - limp home mode . . . . . 107
  - temporary manual selection . . . . . 106

- Transmission (automatic) . . . . . 104
- Transmitters
  - smart key . . . . . 12, 213
- Transporting the vehicle . . . . . 248
- Trim
  - air bag covers (cleaning) . . . . . 199
- U**
- Unlocking . . . . . 9, 17
  - entry and exit mode . . . . . 29
  - global opening . . . . . 11
  - keyless entry . . . . . 11
- Used engine oil . . . . . 193
- Using cruise control . . . . . 126
- Using the parking aid . . . . . 117
- V**
- Valet mode . . . . . 78
  - deselecting . . . . . 78
- Vehicle battery
  - jump starting
    - connecting cables . . . . . 228
    - removing . . . . . 230
- Vehicle cleaning
  - exterior . . . . . 197
  - interior . . . . . 198
  - parking sensors . . . . . 118
- Vehicle data recording . . . . . 251
- Vehicle recovery
  - towing eyes . . . . . 246
  - transporting the vehicle . . . . . 248
- Vehicle settings
  - valet mode . . . . . 78
- Video media player
  - controls . . . . . 160
  - inhibited playback . . . . . 161
- Voice control . . . . . 165
  - navigation POI . . . . . 167
  - training . . . . . 166
  - tutorial . . . . . 166
  - voicetags . . . . . 167
- Voice guidance . . . . . 180
- Volume
  - telephone . . . . . 172
- W**
- Warning lamps . . . . . 67
  - ABS . . . . . 69
  - adaptive front lighting system . . . . . 69
  - AFS . . . . . 69
  - air bag . . . . . 46
  - air bags . . . . . 69
  - ASL (Automatic speed limiter) . . . . . 69
  - brake . . . . . 67
  - Critical warning message . . . . . 67
  - DSC . . . . . 68, 69
  - fog lamps . . . . . 69
  - forward alert . . . . . 70
  - headlamp high beam . . . . . 70
  - lamp test . . . . . 67
  - parking brake . . . . . 68
  - seatbelt . . . . . 68
  - TPMS (Tire pressure monitoring system) . . . . . 70
- Warning symbols (battery) . . . . . 228
- Warranty . . . . . 187
- Washer jets
  - blockages . . . . . 195
- Washers
  - operating . . . . . 54
- Washers (headlamps) . . . . . 55
- Weekly checks . . . . . 192
- Weights . . . . . 210
- Wheel and tires
  - replacements . . . . . 223
  - TPMS (Tire pressure monitoring system)
    - warning lamp . . . . . 70
- Wheels and tires
  - flat spots . . . . . 223
  - punctured . . . . . 223
  - tire care . . . . . 219
  - valves . . . . . 223

# Index

Windows .....	56
anti-trap protection .....	57
reset .....	196
sunroof	
reset .....	196
Windscreen wipers	
speed-dependent mode .....	55
Wipers	
operating .....	54
Wipers and washers	
fluid	
specification .....	206
top up .....	206
operating .....	54
rain sensor .....	55
wipers	
speed-dependent mode .....	55

