


## USING VOICE CONTROL



E151915

**Note:** The voice system has been designed to recognise a number of languages. However, Land Rover cannot guarantee the system will be compatible with every accent group within those languages. Please speak to your Dealer/Authorised Repairer about testing the Voice System for compatibility with a particular accent group.

1. Voice button: Press briefly to start a voice session. Press and hold to cancel a voice session.

**Note:** Briefly press the Voice button during a voice session, to interrupt audible feedback. Wait for the tone to sound before giving the next command.

A voice session will cancel if a high priority warning appears in the message centre or there is no user input for a sustained length of time. It is not possible to start a new voice session until the warning has been cleared.

2. Voice symbol: Indicates that a command is available. Wait for the symbol to appear and a tone to sound before using the command.
3. Command list: Appears in the instrument panel, providing feedback and available commands at each stage of the voice session. Say an available command.

**Note:** As the commands are listed before the system is ready to listen, it is important to wait for the voice symbol to appear alongside the relevant command, before using the command.

4. When displayed, say **Cancel** to cancel the current voice session.
5. When displayed, say **Help** to get assistance during a voice session.

**Note:** The currently selected user (User 1 or User 2) is identified at the bottom of the command list.

**Note:** If a listed item is longer than the available space on the menu, ...> will appear. Use the seek controls on the steering wheel to view the entire entry. See **141, AUDIO/VIDEO CONTROLS.**

## VOICE TUTORIAL

To listen to a tutorial detailing the operation of the Voice system:

1. Briefly press the Voice button to start a voice session.
2. Wait for the tone to sound, then say **Voice tutorial**.

Alternatively, the tutorial can be selected using the Touch screen, as follows.

1. Select **Setup** from the Touch screen Home menu, or by pressing the Setup button.
2. Select **Voice** from the Setup menu.
3. Select **Operating guide** from the Voice settings menu.
4. Select **Voice tutorial**.

The voice tutorial can be cancelled at any time by selecting **Cancel** on the on-screen pop-up or by pressing and holding the Voice button.

## VOICE TRAINING

This is a feature designed to enable the system to better recognise the vocal characteristics of a user, once the training has been completed. To carry out Voice training:

1. Select **Setup** from the Home menu, or by pressing the Setup button.
2. Select **Voice** and from the Setup menu.
3. Select **Voice training** from the Voice settings menu.
4. Select **User 1** or **User 2**, to start the training.
5. Follow the on-screen and audible instructions.

The training session can be cancelled at any time by selecting **Cancel** from the on-screen pop-up or by pressing and holding the Voice button.

## VOICETAGS

Voicetags enable the user to personalise the Voice system so that a single name can be used to call-up a navigation destination, telephone number or radio channel.

To add a Voicetag:

1. Briefly press the Voice button to start a Voice session.
2. Wait for the tone to sound then say **Phone, Navigation** or **Radio**.
3. Say **Store voicetag**.

Alternatively, Voicetags can be managed via the Touch screen as follows:

1. Select **Setup** from the Home menu, or by pressing the Setup button.
2. Select **Voice** from the Setup menu.
3. Select **Voicetags** from the Voice settings menu.
4. Select the system which the Voicetag is to activate (**Phone, Navigation** or **Radio/DAB**).

Follow the on-screen and audible instructions.

## NAVIGATION POI VOICE COMMANDS

To request the display of Points Of Interest (POI) identifiers on the navigation display, say **Navigation** with 1 of the following POI categories:

- Petrol station/Petrol.
- Parking/Car park.
- Land Rover.
- Hospital.
- Golf course.
- Tourist information.

## Voice control

- Restaurant/I'm hungry.
- Shopping centre.
- Hotel.
- Motorway service.
- Town centre.

**Note:** The word **Navigation** must be followed immediately by a category.

Icons will appear on the navigation display, indicating the locations of the selected POI. For further information about POIs, see **185, CATEGORIES AND SUB-CATEGORIES**.