

**Note:** The **Bluetooth®** equipped phones listed, have been tested for compatibility with Land Rover vehicles. Performance will vary, based on the phone's software version, battery condition, coverage, and your network provider. Phones are warranted by their manufacturer, not Land Rover.

## PAIRING AND CONNECTING USING THE PHONE

**Note:** The process of pairing and connecting the phone with the vehicle, will vary depending on the type of cell phone used.

1. Switch the ignition system on and make sure the Touch screen is active.
2. From the **Home menu**, select **Phone**.
3. A menu will appear. Select **Search new**.
4. Select the **Device to vehicle** option.

**Note:** The vehicle's **Bluetooth®** wireless technology system is discoverable for only 3 minutes.

5. Using the cell phone, search for **Bluetooth** wireless technology devices. On some phones, this is referred to as a new paired device. See your phone's operating instructions for further information.
6. When the vehicle's **Bluetooth** wireless technology system is discovered, follow the on-screen instructions. Select **Yes** when prompted, to confirm the pairing. Either the phone or the vehicle's system will ask for a PIN (Personal Identification Number). When prompted, enter a PIN of your choice and select **OK** to confirm.
7. Enter the same PIN into the other device.
8. Once your phone is paired and connected to the system, a confirmation message will be displayed before switching to the Digit dial screen.

**Note:** Some cell phones require the **Bluetooth** wireless technology device pairing to be set as 'authorized' or 'trusted' in order to automatically connect. Please refer to your phone's operating instructions for further information.

## PHONE PAIRING AND CONNECTING USING THE TOUCH SCREEN

1. Switch on the cell phone's **Bluetooth®** wireless technology device connection using the phone's menu. Make sure that the cell phone is in **Bluetooth®** wireless technology device discoverable mode, sometimes referred to as find me mode (see the phone's operating instructions for more information).
2. Switch the ignition on and make sure the Touch screen is active.
3. From the **Home menu**, select **Phone**.
4. A menu will appear. Select **Search new**.
5. Select the **Vehicle to device** option.
6. Identify your phone from the displayed list and select the corresponding **Pair and connect** option.
 

**Note:** If more than 5 phones are detected, it may be necessary to use the scroll bar to see the entire list.
7. When prompted, enter the PIN code into your phone. See your phone's operating instructions for more information.
8. Once your phone is paired and connected to the system, a confirmation message will be displayed before switching to the Digit dial screen.