

Effects of battery disconnection.....	195	Exterior mirrors	
Electric parking brake.....	104	electric.....	61
Electric seats.....	15	manual.....	61
position memory.....	17	mirror dip when reversing.....	61
restricted seat travel.....	16	Extra features.....	75
Electric windows			
operation.....	70		
Electronic brake force distribution.....	103	F	
Emergency (navigation).....	159	Favorite locations.....	158
Emergency brake assist.....	103	details.....	158
Engine		Flat spots.....	209
antifreeze level.....	188	Fluids	
compartment opening.....	173	brake	
coolant level.....	188	check.....	189
engine compartment		specification.....	190
poisonous fluids.....	172	top up.....	190
oil level.....	186	capacities.....	232
specifications.....	230	coolant	
starting		specification.....	188
keyless start backup.....	90	top up.....	188
switching off.....	89	engine oil check.....	186
Engine/transmission warning lamp.....	52	filler locations.....	186
Engine compartment		oil	
fluid filler locations.....	186	top up.....	187
Engine covers.....	173	power steering	
Engine starting.....	89	specification.....	191
failure to start.....	90	power steering check.....	190
Entering a destination.....	156	specifications.....	231
Entering the vehicle		washer fluid.....	192
entry and exit mode.....	27	check.....	191
global opening.....	10	specification.....	192
keyless entry.....	10	Fog lamps	
Ethanol.....	167	warning lamps	
Exiting the vehicle		front.....	53
arming the alarm.....	13	rear.....	53
closing mislock.....	13	Front air bags.....	42
door locks and release levers.....	13	Front climate control.....	76
interior locks.....	13	automatic recirculation.....	77
keyless locking.....	13	Front parking aids.....	106
Extended mode (air suspension).....	100	system fault.....	107
Exterior cleaning.....	183	Front wipers.....	58
Exterior lamps		Fuel and refueling.....	168
bulb changing.....	174	ethanol.....	167
bulb specification.....	235	filler flap.....	168
		fuel filler flap.....	168