

A

- About this handbook.....2
- Access height (air suspension).....101
- Accessories.....170
- Adaptive front lighting system.....56
 - warning lamp.....53
- Adaptive headlamps.....56
- Age degradation (tires).....209
- Air bags
 - curtain.....43
 - deployment.....41, 45
 - disability modifications.....46
 - front.....42
 - locations.....41
 - obstructions.....44
 - service information.....46
 - side.....43
 - warning lamp.....45, 53
- Air conditioning
 - automatic recirculation.....77
 - auto setting.....77
 - fluid top up.....170
 - front.....76
 - rear.....78
- Air quality sensor.....77
- Air suspension.....100
 - access height.....101
 - extended mode.....100
 - locked access height.....101
 - off-road height.....100
 - remote operation.....101
- Alarm
 - deactivating.....14
- Anchor points (LATCH).....38
- Anchor points (luggage).....83
- Anti-lock braking system (ABS) warning lamp.....52
- Anti-trap protection
 - windows.....71
- Arduous driving conditions.....171
- Audio
 - automatic station retune.....125
 - CD loading.....119
 - changing portable media device.....135
 - connecting portable media devices.....133
 - DVD player controls.....136
 - full screen view.....137
 - HD digital channels.....129
 - HD radio reception.....129
 - headphones.....140
 - portable media connections.....132
 - portable media controls.....130
 - portable media pairing.....134–135
 - portable media playing.....134
 - radio controls.....124
 - radio national alert.....125
 - rear media touch screen control.....138
 - satellite radio controls.....126
 - satellite radio reception.....127
 - satellite subscription.....127
 - sound settings.....119
 - touch screen controls.....118
 - video player controls.....136
- Automatic locking.....11
- Automatic recirculation.....77
- Automatic transmission.....94
 - gear shift indicator.....96
 - hill descent.....96
 - range change indicators.....97
 - shift paddles.....96
 - stationary range changing.....96
 - temporary manual selection.....96
 - transfer gearbox.....96
- Auto mode (climate).....77
- Auto zoom (navigation).....155
- Auxiliary device connection.....134
- Auxiliary power sockets.....81

B

- Battery
 - boost starting.....195
 - care.....193
 - charging.....196
 - connecting jump leads.....194
 - effects of disconnection.....195
 - monitoring system.....197
 - replacing.....196