## Warning lamps

If the lamp flashes, HDC has been selected, but the operating conditions are not being met or HDC fade-out is occurring.

## **LOW RANGE (GREEN)**



Illuminates when Low range has been selected.

## **CRUISE CONTROL (GREEN)**



Illuminates when Cruise control is active.

## TRAILER TURN SIGNALS (GREEN)



Illuminates, as a bulb check, when the ignition is switched on and extinguishes when the engine is started.

If a trailer is attached, the warning lamp will flash in conjunction with the turn signal warning lamp. If the lamp fails to flash, the turn signal bulb on the trailer may be faulty.