

- Cleaning
 - after off-road driving.....183
 - air bag covers.....184
 - exterior.....183
 - interior.....183
 - leather.....184
 - parking sensors.....107
 - seat belts.....184
 - under body.....183
 - washer jets.....185
- Climate control
 - automatic recirculation.....77
 - auto setting.....77
 - front.....76
 - rear.....78
- Clock.....47
- Closing the hood.....173
- Closing vehicle sensing.....65
- Compact disc.....119
- Condensation (headlamps).....56
- Connecting jump leads.....194
- Coolant
 - checking the level.....188
 - specification.....188
 - top up.....188
- Courtesy delay.....55
- Covers
 - engine.....173
- Critical warning messages.....51
- Cruise control.....111
 - warning lamp.....54
- D**
 - Data recording.....229
 - Daytime running lamps.....55
 - Declaration of conformity.....149
 - Deselecting valet mode.....74
 - Destination entry.....156
 - state.....156
 - Detachable tow hitch.....88
 - removing.....88
 - Dimensions.....233
 - Direction indicators.....55
 - Door mirrors.....61
 - blind spot monitor.....63
 - closing vehicle sensing.....65
 - sensors.....66
 - Door transceiver
 - assistance.....69
 - erase all programming.....68
 - garage door opener.....67
 - programming.....67
 - programming a single button.....69
 - programming the garage door opener.....68
 - rolling code device programming.....68
 - Drive away locking.....11
 - Driving
 - activating intelligent stop/start.....92
 - after a collision.....229
 - arduous conditions.....171
 - before starting.....229
 - blind spot monitor.....63
 - closing vehicle sensing.....65
 - blind spot monitor messages.....66
 - brake control with ABS.....103
 - brakes important information.....103
 - daily checks.....171
 - deactivating intelligent stop/start.....92
 - DSC active warning lamp.....52
 - electronic brake force distribution.....103
 - emergency brake assist.....103
 - low oil pressure.....51
 - rain sensor.....60
 - roll stability control (RSC).....99
 - sitting correctly.....16
 - steep slope control with ABS.....103
 - using cruise control.....111
 - weekly checks.....171
 - Driving position memory.....17
 - Dynamic stability control (DSC)
 - DSC active warning lamp.....52
 - DSC off warning lamp.....52
 - roll stability control (RSC).....99
 - switching off.....98
 - switching on.....98
- E**
 - Easy route.....157