


REAR MEDIA CONTROL FROM THE TOUCH SCREEN



Touch **Rear media** on the Audio/video home menu to select the Rear media control screen.

1. Information display.
2. Touch to select the left side rear screen.
3. Touch to synchronize both screens, then select the source to be synchronized.

Note: Pressing the synchronize button will not synchronize a source already selected.

4. Touch to select the right side rear screen.

5. **Limo. mode:** Touch to turn Limousine mode ON/OFF. When Limousine mode is turned **ON**, the rear passengers will have control of the total cabin Audio system and any shared sources via the remote control.
6. **Lock:** Touch to lock or unlock the Rear media remote.
7. **System:** Touch to turn the selected rear screen/s ON/OFF.