

DRIVER CONTROLS

1. Map reading lamps switch (57).
2. Main interior lamp switch (57).
3. Sunroof open/close switch (70).
4. Sunroof close/tilt switch (70).
5. High beam/Direction indicator/Trip computer switch (55/49).
6. Gearshift paddle (94).
7. Audio system control (118).
8. Instrument panel and Message center (47).
9. Instrument panel menu control (48).
10. Wiper/washer controls (58).
11. START/STOP button (89).
12. Audio system and controls (118).
13. Display/Touch screen (72).
14. Left side heated seat switch (76).
15. Dynamic Stability Control (DSC) off switch (98).
16. Hazard warning lamp control switch.
17. Parking aid switch (106).
18. Right side heated seat switch (76).
19. Heater/air conditioning control (76).
20. Terrain response switch (112).
21. Transfer gearbox switch (96).
22. Intelligent stop/start (92).
23. Rotary gear selector (94).
24. Electric Parking Brake (EPB) (104).
25. Air suspension control (100).
26. Hill Descent Control (HDC) switch (114).
27. Heated steering wheel switch (27).
28. Voice recognition and telephone switches (142/148).
29. Horn switches.
30. Cruise control switches (111).
31. Electric mirror controls (61).
32. Electric window controls (70).
33. Electric window rear isolator switch (70).
34. Front fog lamp switch (55).
35. Rear fog lamp switch (55).
36. Instrument illumination dimmer control (55).
37. Main exterior lamp control (55).

