


Rear seats

FOLDING THE SEATS (7 seat vehicle)



One of the seats may be folded to form a table for the other two seats, or all three seats may be folded forward to extend the loadspace. A seat may also be folded to gain access to the 3rd row seats.

Note: The rear seats may not be folded if the front seats are in their furthest rearward position.

Note: The center seat back must always be folded first.

1. Pull the seat back release lever forwards.
2. Fold the seat back forwards into the table fold position.
3. Pull the strap at the front of the seat and press down to fold into the loadspace extension position.
4. The loadspace cover may be stowed as shown behind the folded seats.

RAISING THE SEATS (7 seat vehicle)

⚠ WARNING

Always check and physically test that the cushions and the seat backs are secure before driving. If the seat backs are not fully locked in place, red markers will be visible around the seat back release levers. Unsecured seat cushions and seat backs may not properly restrain an occupant during a collision or sudden stop.

⚠ WARNING

When raising the rear seats, make sure that seat belts are correctly routed in the seat belt guides and not trapped behind the seats.

NOTICE

Do not attempt to raise the seats when the loadspace cover is stowed behind them. Damage to the loadspace cover will result.