

Wipers and washers



This feature can be enabled/disabled by your Retailer/Authorized Repairer.

Rear wiper

The frequency of the intermittent rear wiper will increase when the vehicle's speed increases.



This feature can be enabled/disabled by your Retailer/Authorized Repairer.

Switching the headlamps or ignition off and back on again, will reset the cycle.

Note: *The headlamp washers are inhibited when the washer fluid reservoir level is low.*

RAIN SENSOR

The Rain sensor (if fitted) is mounted on the inside of the windshield, behind the rear-view mirror. The sensor is able to detect the presence and amount of water on the windshield and automatically activate the windshield wipers accordingly.

Note: *Static droplets may not be detected on the initial start-up. A single wipe should be used to clear the windshield.*

To activate the Rain sensitive wipers, move the wiper control to the **AUTO** position (1). The behavior of the system may be adjusted to the driver's preference by rotating the collar (2).

Note: *In dry and often sunny conditions, optical influences and dirt accumulation on the windshield may result in the windshield wipers activating inadvertently. To prevent this, it is recommended that, under these conditions, the wiper controls are returned to the **OFF** position.*

HEADLAMP WASHERS

If the headlamps are on, and there is sufficient liquid in the washer reservoir, operating the screen wash will also power wash the headlamps.

The headlamp power wash will operate on every fifth operation of the screen washer, provided the headlamps are still switched on and approximately 10 minutes have elapsed since the last headlamp wash.