## Navigation system

## SETTING A DESTINATION

- **1.** After touching **Agree**, the initial map screen is displayed, now touch **Nav menu**.
- 2. From the Navigation menu, touch **Destination entry**.
- **3.** Touch **Address** from the **Destination** screen and input the town name or postcode.
- Once sufficient letters have been entered, touch **OK** or **List** to display all of the possible towns.
- **5.** If necessary, use the scroll arrows to the left of the list to search up or down. Select the town you require.
- Now enter the road name. Once sufficient letters have been entered, touch OK or List to display all of the possible roads.
- Select the road you require. Enter the house number of the address (if known) and then touch **OK** to confirm.
- If the house number is not known, select OK; the end of the road is then used as the destination.
- 9. The map screen showing the selected destination details is displayed. Touch GO to calculate the default quick route, or Review route for alternative routes.
- **10.** Touch **GO** to start the journey.

## START GUIDANCE

After selecting **Review route**, the system will calculate the route.

 There is now a choice to select 3 Routes, Change route, or select GO to start Navigation guidance.

- Touch 3 Routes to display a choice of 3 different route options on the map. The roads on the map are drawn in 3 different colours to highlight each route. EcoRoute helps you find the most fuel-efficient route available. A display of 3 leaves indicates the most fuel-efficient route.
- Select route 1, 2 or 3 by touching the respective box displayed on the right side of the map.
- 4. Touch Change Route followed by Route Preferences to change the route settings. If a destination is already set, touch Waypoint to add a waypoint in the journey, if required.
- When you have made your selection, if any, touch GO.

**Note:** As you approach a junction, in addition to the Voice guidance, an inset on the map will display an enlarged view of the junction.

## **AVOID POINTS**

When calculating a route, an area to avoid can be set and stored.

- 1. From the Nav menu, touch More....
- 2. Select Stored locations.
- 3. Select Avoid points.
- 4. Select Add.
- 5. Select the location of the area to avoid from the **Destination entry** menu. Touch **OK** to activate the view where the size of the area to avoid can be set. The size of the area can be adjusted by using the '+' and '-' symbols.
- Touch OK. The area to avoid is now set and stored.

To edit or delete an area to avoid from the stored list.

- 1. From the Nav menu, touch More....
- 2. Select Stored locations.