Traffic information
standard audio RDS....132
Traffic message channel (TMC)....124
Trailer
electrical connections....66
weights
maximum weights....66
Trailer direction indicators warning lamp....37
Transmission
automatic....72
fault....73
gear shift warning lamp....36
hill descent....73
manual....73
Transmitters
smart key....207
Trip computer....32
average speed....32
fuel consumption....32
fuel range....33
reset....32
trip distance....33
Tyre pressure checking after a repair....192
Tyre pressure monitoring system (TPMS)..188
full size replacements....189
tyre care....183
valves....184
warning lamp....36
Tyre repair kit
checking pressures....192
repair procedure....191
safety information....190
using....190
Tyres
age degradation....186
changing....189
flat spots....186
full size replacements....189
important information....196
Indian regulations....187
pressures....183
punctured....184
repair kit....190
repair kit use....190
repair procedure....191
replacements....184
snow chains....186
speed ratings....183
temporary use spare....189
TPMS....188
warning lamp....36
TPMS pressure compensation....186
tyre care....183
tyre repair safety....190
tyre wall markings....182
use of spare tyre....196
valves....184
wall markings....182
winter....185

U

Under body cleaning....161
Under bonnet covers....152
Unlocking....9
all doors....4
driver's door....4
global opening....4
mode....4
multi point entry....4
single point entry....4
USB devices
connecting multiple devices....99
Used engine oil....150
Using cruise control....80
Using the parking aids....77
Using the spare tyre
important information....196

V

Valet mode....53
deselecting....53
Vehicle alarm....147
Vehicle battery
connecting jump leads....169
effects of disconnection....172
replacing....171
warning symbols....168