Vehicle battery

- 2. Remove the Smart key from the vehicle and wait for 2 minutes to allow the systems to power down fully.
- 3. Undo the negative clamp, and lift the cable and clamp clear of the battery terminal.
- **4.** Undo the positive clamp, and lift the cable and clamp clear of the battery terminal.
- **5.** Undo the battery clamp and lift the battery clear of the vehicle.

A new battery should be supplied with plastic terminal covers. Leave the covers in place when fitting the battery, and remove them one at a time to fit the battery cable clamps.

Refitting is an exact reversal of the removal procedure. If you are in any doubt about fitting a battery, seek qualified assistance before attempting to fit the battery.



Used batteries must be disposed of correctly as they contain a number of harmful substances. Seek advice on disposal from your Dealer/ Authorised Repairer and/or your local authority.

EFFECTS OF DISCONNECTING

Disconnecting the battery can affect a number of vehicle systems, especially if there is insufficient battery power prior to disconnection. For example, the alarm may trigger depending on its state when the battery was disconnected. If the alarm does sound, use the Smart key in the normal way to disarm the security system. The windows may need recalibrating to operate correctly.