


MAIN MENU



E141771

1. **More...:** Displays the other Nav menu screen.
2. **Cancel guidance:** Cancels the current route guidance.
3. **Destination entry:** Provides a choice of options for entering a destination.
4. **Previous destination:** Displays previous destinations entered.
5. **Display/Hide POI:** Turns the POI (Point Of Interest) icons on the map on/off.
6. When a destination is set, the Range Rover logo is replaced by a soft key which enables the last voice instruction to be repeated.
7. **Route voice guidance:** Allows the Voice guidance messages to be turned off for the current journey. The soft key is highlighted while Voice guidance is enabled.
8. **Quick POI shortcuts:** This provides the option to quickly enter a destination of a local POI. The categories can be changed in the Navigation set-up menu.
9. **Return to map:** Advances to the main map screen.
10. **Detour:** Allows a detour from the current route.
11. **Nav set-up:** Settings for the Navigation system.
12. **Route options:** Allows the user to select different route options.
13. **TMC:** Traffic Message Channel.
14. **Stored locations:** Allows the user to select from previously stored locations.

- 12. Route options:** Allows selection of various options for the route.
- 13. TMC (Traffic Message Channel):** Not used for entering a destination but, when enabled, will provide data about road conditions and any events that may affect the journey.
- 14. Stored locations:** Manages the stored locations.