Lamps....38
bulb changing....152
bulb replacement....154
bulb specification....206
condensation....39
test....34
TPMS warning lamp....36
warning lamps....34
xenon headlamps....153
Leather cleaning....161
Licence plate bulb....158
Lighting
interior lamps locations....40
Load securing....63
Loadspace cover....63
Loadspace floor
reversible cover....64
Locking
door locks and release levers....9
double locking....8
drive away....6
global closing....8
mislock....9
single....8
Locking wheel nuts....196
Low oil pressure warning lamp....34
Lubricants specifications....202
Luggage compartment
anchor points....63
loadspace cover....63–64
loadspace floor....64

M

Maintenance
after off-road driving....161
arduous driving conditions....148
brake fluid level....165
brake pads....147
bulb changing....152–153
bulb specification....206
capacities....203
changing a fuse....174
checking tyre pressure after a repair....192
cleaning
exterior....161
interior....161
leather....161
parking sensors....78
seat belts....162
under body....161
closing the bonnet....150
daily checks....147
diesel particulate filter (DPF)....148
engine compartment....151
engine compartment fuse box....175
engine coolant level....164
engine oil level....163
fuel system....149
fuse box (passenger compartment)....177
jump starting....170
label locations....200
lubricants and fluid specifications....202
luggage compartment fuse box....181
number plate bulb....158
oil top up....163
power steering fluid level....166
smart key battery....7
tyre repair kit....190
tyre repair procedure....191
using a starting aid....170
washer fluid level....167
washer jets....152
weekly checks....147
wheel balancing....148
Manual seats....10
Map....120
auto zoom....116
split screen....116
Message centre display units....33
Methanol....140
Mirrors
dip when reversing....45
exterior mirrors....44
Misfuel device....142
Motorway entry/exit
route setting....121
MP3 files....139