
DRIVER CONTROLS

For further information on the numbered item, refer to the page number.

1. Roof blind switch. See **65**.
2. Front interior courtesy lamp. See **50**.
3. Front map/reading lamps. See **50**.
4. Breakdown call button.
5. SOS emergency call button.
6. Exterior lamps and Trip computer control. See **47** and **41**.
7. Audio/Video system control. See **126**.
8. Instrument panel and Message centre. See **40**.
9. Instrument panel menu control. See **40**.
10. Wipers and washers control. See **52**.
11. START/STOP button. See **85**.
12. Touch screen display. See **67**.
13. Audio system. See **126**.
14. Hazard warning lamps switch.
15. Heating, ventilation and air conditioning controls. See **71**.
16. Intelligent stop/start button. See **87**.
17. Hill Descent Control (HDC) button. See **117**.
18. Dynamic Stability Control (DSC) button. See **92**.
19. Automatic transmission gear selector. See **89**.
20. Terrain Response control. See **115**.
21. Manual transmission gear selector. See **91**.
22. Electric parking brake. See **96**.
23. Audio on/off/volume control. See **126**.
24. Upshift gear paddle. See **89**.
25. Adaptive cruise control buttons. See **108**.
26. Cruise control or Adaptive cruise control buttons. See **107** and **108**.
27. Steering column adjustment lever. See **24**.
28. Horn.
29. Telephone and voice control buttons. See **158**.
30. Headlamp levelling control. See **49**.
31. Interior lamp illumination control. See **51**.
32. Bonnet release lever. See **198**.
33. Lane departure warning button. See **122**.
34. Tailgate release/open button. See **9**.
35. Heated steering wheel button. See **24**.
36. Downshift gear paddle. See **89**.
37. Rear window isolator switch. See **65**.
38. Window switches. See **65**.
39. Mirror adjustment/power-folding control. See **56**.
40. Central locking/unlocking buttons. See **15**.
41. Driving position memory buttons. See **18**.


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
RANGE ROVER
AIRBAG
START STOP
SL2463