# **Navigation system**

When **On** is selected, if you make the same deviation from the proposed route 3 times, then the system will memorise the deviation and offer that as the normal route from then on. Select **Reset all routes** to delete any learnt routes and return to the default settings.

# **VOICE GUIDANCE**

To turn Voice guidance on or off, but maintain Route guidance, proceed as follows:

- 1. Touch Nav menu on the navigation screen.
- Touch the Route voice guidance soft key. The soft key will be highlighted when Voice guidance is enabled.

#### CANCEL ROUTE GUIDANCE

To clear the route, proceed as follows:

- 1. Touch Nav menu on the navigation screen.
- 2. Touch the Cancel guidance soft key.

# QUICK POI SELECTION

To select a Quick POI proceed as follows:

- 1. Touch the map to display the additional options.
- 2. Touch the Point Of Interest (POI) soft key.
- The screen shows 6 suggested categories, 5 of which can be selected as quick Point Of Interest (POI).
- Select a Quick POI category, or touch More to see further POIs. Touch Ok to confirm a selection.
- The map with the POI icon(s) is displayed. Scroll the map to the POI icon and then touch **Set destination** to set and calculate the route.
- **6.** Touch **GO** to start the journey.

**Note:** Selected POIs can be hidden if required by selecting **Nav menu** followed by **Hide POI**.

**Note:** POI icons can only be displayed up to the 1 km (½ mile) zoom level.

## RESTORE SYSTEM DEFAULTS

From the Navigation menu, press **More...** and then select **Nav setup**. If you have made any changes to the system's default settings, use this menu to restore the original settings.

#### **FAVOURITES**

This enables you to manage destinations such as, place of work, home, favourite restaurant.

From the favourites sub-menu in stored locations, you can save up to 400 stored favourites.

- 1. From the Nav menu, touch More....
- 2. Select Stored locations.
- Touch Favourite.
- **4.** To store a favourite, select **Add** from the sub-menu.
- **5.** Select any destination entry method and confirm the desired location.

## **FAVOURITES DETAILS**

- 1. From the **Stored locations** menu, select **Favourite**.
- 2. Select Fdit or Delete
- 3. Touch the selected favourite to display the details.
- Select the chosen detail to edit. Details include Attribute, Name, Phone number, Location and Icon.