

- Panoramic roof blind
 - operation.....65
 - Park assist
 - cleaning sensors.....208
 - limitations of use.....105
 - park out.....104
 - selecting.....103
 - troubleshooting.....106
 - Parking aids
 - cleaning sensors.....208
 - operating.....98
 - rear camera.....99, 102
 - reverse traffic detection.....101
 - sensor cleaning.....99
 - system fault.....99
 - Parking brake.....96
 - warning lamp.....43
 - Parts.....197
 - Passenger compartment fuse box.....226
 - Petrol
 - fuel types.....190
 - specification.....193
 - Petrol consumption.....193
 - Petrol filler flap.....192
 - emergency release.....191
 - Phone.....189
 - answering a call.....189
 - Bluetooth compatibility.....156, 187
 - call volume.....159
 - change the phone.....158
 - dialling.....189
 - ending a call.....189
 - hands free operation.....188
 - icons.....158
 - making calls.....189
 - overview.....155
 - pairing to the system.....189
 - pairing via the phone.....156
 - pairing via the touch screen.....157
 - phonebook.....159
 - rejecting a call.....189
 - safety.....156, 188
 - steering wheel controls.....158
 - Points of interest (POI).....169
 - my POI.....169
 - search.....170
 - Portable media
 - changing device.....142
 - connecting a device.....186
 - connecting devices.....139, 187
 - connecting multiple devices.....140
 - connections.....139
 - connection via AUX socket.....186
 - connection via USB/iPod socket.....186
 - controls.....137, 185
 - MP3 file playing.....186
 - MP3 files repeat and shuffle.....186
 - pairing.....141
 - playing.....140
 - Portable media controls
 - standard audio.....177
 - Postcode
 - destination entry.....168
 - Powered tailgate.....9
 - opening height.....9
 - Power sockets.....77
 - Preset buttons
 - storing a radio station.....180
 - Pressure checking (tyres)
 - checking after a repair.....243
 - Pressures
 - tyres.....233
 - Previous destination.....168
 - Programming the timed climate.....74
 - Puncture repair kit.....241
 - instructions for use.....241
 - repair procedure.....242
 - safety.....241
- ## Q
- Queue assist (ACC).....110
 - Quick POI selection.....167
- ## R
- Radio
 - automatic station retune.....133
 - controls.....132

Index

- DAB.....134
 - settings.....135
 - stations.....136
- Radio (Standard).....182
 - adaptive volume control.....178
 - alternative frequencies.....181
 - automatic station retune.....180
 - controls.....177, 179
 - DAB ensemble seek.....182
 - DAB messages.....184
 - DAB radio manual tuning.....183
 - DAB radio presets.....182
 - DAB service list.....183
 - news information.....181
 - preset buttons.....180
 - station autostore.....180
 - station lock.....180
 - tone.....178
 - traffic announcement volume.....181
 - traffic information.....181
- Radio data system (RDS)
 - auto retune.....180
- Radio data system auto retune.....133
- Rain sensor.....53
- RDS
 - news information.....181
 - TMC.....172
 - icons.....171
 - overview.....170
 - traffic information.....181
- Rear camera
 - hitch assist.....81
 - parking aids.....99
 - reverse traffic detection.....101
 - sensors.....102
- Rear fog lamps warning lamp.....45
- Rear media
 - headphones.....148, 151
 - remote control batteries.....152
 - remote control use.....150–151
 - touch screen control.....149
- Rear screen cleaning.....209
- Rear seats
 - folding and raising.....21
- Recording
 - event data.....252
 - service data.....252
- Recovery
 - off-road.....251
 - towing points.....250
 - transporting.....249
- Reformulated gasoline.....191
- Refuelling
 - diesel.....191
 - diesel fuel sulphur content.....191
 - ethanol.....190
 - methanol.....190
 - MTBE.....190
 - octane rating.....190
 - petrol.....190
 - reformulated gasoline.....191
 - running out of fuel.....191
 - safety precautions.....190
- Regional mode.....180
- Reminder (seat belt).....27
- Remote control
 - care.....11
 - driving position memory.....18
 - rear media.....150–151
 - batteries.....152
 - single locking.....12
 - smart key battery.....10
 - system transmitters.....263
- Removing the spare wheel.....246
- Removing the vehicle battery.....220
- Repairing paintwork damage.....211
- Replacement tyres.....236
- Resetting the windows.....207
- Restarting the engine while moving.....85
- Restore navigation default settings.....167
- Restricted seat travel.....18
- Resume speed and follow mode (ACC).....111
- Reverse parking aids.....98
 - rear camera.....102
 - reverse traffic detection.....101
 - system fault.....99
- Road sign recognition.....121
- Rolling re-start.....85