
REAR MEDIA CONTROL FROM THE TOUCH SCREEN



E157297

Touch **Rear media** on the Audio/video home menu to select the Rear media control screen.

- Information display.
- 2. Touch to select the left-side rear screen.
- **3.** Touch to synchronise both screens. Then select the source to be synchronised.

Note: Pressing the synchronise button will not synchronise a source already selected.

4. Touch to select the right-side rear screen.

5. Limo mode: Touch to turn Limousine mode ON/OFF.

When Limousine mode is turned ON, the rear passengers will have control of the total cabin audio system and any shared sources via the remote control.

- Lock: Touch to lock or unlock the rear media remote.
- System: Touch to turn the selected rear screen/s ON/OFF.